







This section shows how to remove your Fuel Injection Components


Per chance you need to replace an injector or clean your throttle body.































Although this guide doesn't have a price tag it is copyrighted and formally registered. If you like what you see and this has helped you, please make a donation via **PAYPAL** to **richard@coote1.com**. Your support will help make more manuals like this available.

If you haven't helped yet, please donate so I can continue to offer these guides.

We are slowly developing useful tools to help make it easier for you to work on your pride and joy. Specialty hand crafted tools for your modern Norton by **One07 Tools**, can be purchased from places like **Colorado Norton Works in the USA**. If there are any tools in this manual or other manuals you would like more information on, please email me at **richard@coote1.com**



Norton SE#107 on the Blue Ridge Parkway, NC, USA, July 2015