







This section shows how to replace and correctly set the tension of the Split Balance Gear Spring. You may need to refer to the “Removing Primary Side Cover” section.




























Although this guide doesn't have a price tag it is copyrighted and formally registered. If you like what you see and this has helped you, please make a donation via **PAYPAL** to **richard@coote1.com**. Your support will help make more manuals like this available. If you haven't helped yet please donate so I can continue to offer these guides.

If there are any tools in this manual you would like to purchase, please email me at **richard@coote1.com** for prices and availability. We are slowly developing useful tools to help make it easier for you to work on your pride and joy.



**2014 Norton Commando SE#112 (Left)      2013 Norton Commando SE #107 (Right)**