

# Chaincases, Chains, Sprockets, Clutch, Alternator

10

Plate No.	Part No.	Description	Qty.	Bin No.	Price
1	060374	Chaincase Inner Half c/w Dowels	1	.....	.....
2	060769	Chaincase Oil Seal Disc	2	.....	.....
3	024145	Chaincase Dowel	2	.....	.....
4	012443	Chaincase Felt Seal	1	.....	.....
5	060711	Chaincase to Crankcase Gasket	1	.....	.....
6	062669	Chaincase Fixing Bolt	3	.....	.....
7	060395	Chaincase Fixing Bolt Washer	3	.....	.....
8	060376	Chaincase Centre Stud	1	.....	.....
9	000010	Chaincase Centre Stud Washer	2	.....	.....
10	060397	Chaincase Centre Stud Nut	1	.....	.....
11	060399	Chaincase Centre Stud Shim	AR	.....	.....
12	060386	Stator Stud	3	.....	.....
13	060377	Stator Stud Spacer	3	.....	.....
14	000011	Stator Stud Washer	3	.....	.....
15	060700	Stator Stud Nut	3	.....	.....
16	062585	Chaincase Outer Half with Timing Plate	1	.....	.....
17	060763	Ignition Indicator Plate	1	.....	.....
18	060663	Hammer Drive Screw	2	.....	.....
19	060388	Chain Inspection Cap	2	.....	.....
20	062581	Chain Inspection Cap 'O' Ring	2	.....	.....
21	060659	Timing Inspection Cap	1	.....	.....
22	062580	Timing Inspection Cap 'O' Ring	1	.....	.....
23	060398	Chaincase Band Rubber	1	.....	.....
24	060367	Chaincase Attachment Nut	1	.....	.....
25	060368	Chaincase Attachment Nut Washer	1	.....	.....
26	060383	Engine Sprocket	1	.....	.....
27	NME3682	Engine Sprocket Key	1	.....	.....
28	54212006	Rotor	1	.....	.....
29	47205A	Stator	1	.....	.....
30	060903	Alternator Grommet	1	.....	.....
31	060402	Rotor Spacer	1	.....	.....
32	060665	Rotor Shim .010"	AR	.....	.....
33	060664	Rotor Shim .036"	AR	.....	.....
34	NM20948	Rotor Key	1	.....	.....
35	NM24948	Rotor Washer	1	.....	.....
36	060387	Rotor Nut	1	.....	.....
37	060366	Front Chain (Primary)	1	.....	.....
38	062582	Chaincase Oil Level Plug	1	.....	.....
39	062583	Chaincase Oil Level 'O' Ring	1	.....	.....
40	064644	Clutch Complete (includes items 41-46, 49-52 inclusive)	1	.....	.....
41	062482	Clutch Sprocket c/w Backplate	1	.....	.....
42	063741	Clutch Friction Plate, Sintered Bronze	5	.....	.....
43	060746	Clutch Plain Plate	4	.....	.....
44	063768	Clutch Pressure Plate	1	.....	.....
45	063979	Clutch Centre	1	.....	.....
46	060770	Clutch Spring Plate with Centre	1	.....	.....
47	061179	Clutch Adjuster	1	.....	.....
48	060005	Clutch Adjuster Nut	1	.....	.....
49	060750	Clutch Bearing	1	.....	.....
50	060753	Clutch Bearing Inner Circlip	1	.....	.....
51	060754	Clutch Bearing Outer Circlip	1	.....	.....
52	060751	Clutch Spring Circlip	1	.....	.....
53	060752	Clutch Location Circlip	1	.....	.....
54	060747	Clutch Location Spacer	1	.....	.....
55	060894	Clutch Location Shim .036"	AR	.....	.....
56	060895	Clutch Location Shim .048"	AR	.....	.....
57	040373	Clutch Fixing Nut	1	.....	.....
58	063447	Clutch Fixing Nut Washer	1	.....	.....
59	017376	Rear Chain, 98 Links (for 19 tooth sprocket)	1	.....	.....
59A	064025	Rear Chain, 99 Links (for 21 tooth sprocket)	1	.....	.....
59B	065441	Rear Chain, 100 links (for 22 tooth sprocket)	1 MK2A	.....	.....
60	063459	Tab Washer	1	.....	.....

## Carburetors

11

Part No.		Description	Qty.	Bin No.	Price
1	064232	Carburetor L.H. L932/30 30 mm	1	.....	.....
1A	065749	Carburetor L.H. 850 MK2A (L932/34)	1	.....	.....
2	L932/011	Mixing Chamber R.H. 32 mm	1	.....	.....
2A	065750	Carburetor R.H. 850 MK2A (R932/33)	1	.....	.....
3	064233	Carburetor R.H. R932/29	1	.....	.....
4	R932/005	Mixing Chamber R.H. 32 mm	1	.....	.....
5	928/060	Throttle Valve (quote size)	2	.....	.....
6	928/062	Air Valve	2	.....	.....
7	928/103	Air Valve Guide	2	.....	.....
8	622/131	Throttle Valve Spring	2	.....	.....
9	622/129	Air Valve Spring	2	.....	.....
10	622/067	Needle Clip	2	.....	.....
11	928/104	Throttle Needle (use with Spray Tube 928/107)	2	.....	.....
12	622/055	Float Chamber Body	2	.....	.....
13	622/068	Float Needle	2	.....	.....
14	622/069	Float	2	.....	.....
15	622/071	Float Spindle	2	.....	.....
16	622/073	Float Chamber Gasket	2	.....	.....
17	622/147	Float Chamber Drain Plug	2	.....	.....
18	622/151	Float Chamber Drain Plug Gasket	2	.....	.....
19	622/076	Pilot Air Screw	2	.....	.....
20	622/082	Friction Ring	2	.....	.....
21	622/077	Throttle Stop	2	.....	.....
22	928/107	Spray Tube	2	.....	.....
23	622/128	Jet Holder	2	.....	.....
24	622/122	Needle Jet	2	.....	.....
25	376/100	Main Jet (quote size)	2	.....	.....
26	928/064	Mixing Chamber Top	2	.....	.....
27	4/035	Cable Adjuster	4	.....	.....
28	5/077	Adjuster Locknut	4	.....	.....
29	622/086	Screw Float Chamber and Carburetor Top	4	.....	.....
30	033281	'O' Ring	2	.....	.....
31	622/078	Banjo Bolt	2	.....	.....
32	376/093	Filter	2	.....	.....
33	622/172	Waterproof Tickler Complete	1	.....	.....
-	622/087	Mixing Chamber Plug	1	.....	.....

# Carburetor Mountings, Air Filter and Fuel Line

12

Plate No.	Part No.	Description	Qty.	Bin No.	Price
1	063458	Carburetor Heat Insulator (32 mm carb.)	2	.....	.....
1A	NM23358	Carburetor Heat Insulator (30 mm carb.)	2	.....	.....
2	062711	Carburetor Spacer (32 mm carb.)	2	.....	.....
2A	065196	Carburetor Spacer (30mm carb.)	2	.....	.....
3	060577	Carburetor Stud	4	.....	.....
4	060348	Carburetor Stud Nut	4	.....	.....
5	22528	Carburetor Stud Washer	4	.....	.....
6	062536	Carburetor Fixing Screw	4	.....	.....
7	11796	Carburetor Fixing Screw Washer	4	.....	.....
8	062284	Balance Pipe Hose	1	.....	.....
9	062537	Hose	2	.....	.....
10	063813	Front Plate, Air Cleaner	1	.....	.....
12	064894	Back Plate, Air Cleaner	1	.....	.....
13	060900	Bolt	2	.....	.....
14	000012	Washer	5	.....	.....
15	060926	Locking Plate	1	.....	.....
16	061556	Air Cleaning Element	1	.....	.....
17	060816	Perforated	1	.....	.....
18	033027	Air Cleaning Adaptor Sleeve	2	.....	.....
19	065192	Fuel Line Assembly	1	.....	.....
20	062344	'T' Piece for Fuel Pipe	2	.....	.....
21	060327	Air Cleaning Fixing Bolt	2	.....	.....
22	060617	Bolt	1	.....	.....
23	000012	Plain Washer	2	.....	.....
24	062170	Spacer	1	.....	.....
25	033057	Nut	1	.....	.....
—	065601	Airbox	1	} MK2A	.....
—	064839	Venturi	2		.....
—	065372	Clip	2		.....
—	064536	Element	1		.....
—	064133	Plate, Cover	1		.....
—	064174	Joint	1		.....
—	060677	Bolt	3		.....
—	27758	Washer	3		.....
—	064180	Hose	2		.....
—	064111	Bracket, Switch	1		.....
—	000012	Washer	4		.....
—	060327	Bolt	4		.....
—	064237	Bracket, Top	1		.....
—	065368	Rubber Seal Washer	2		.....
—	065369	Rubber Seal Washer	4		.....
—	065371	Packing	1		.....
—	064220	Packing	1		.....

## Engine Mountings, Head Steady, Centre Stand

13

Plate No.	Part No.	Description	Qty.	Bin No.	Price
1	065459	Engine Steady	1	.....	.....
2	NM.19437	Engine Steady to Head Screw	3	.....	.....
3	014117	Engine Steady Screw Washer	3	.....	.....
4	061128	Engine Steady Side Plate	2	.....	.....
5	060490	Engine Steady Spacer	2	.....	.....
6	060622	Engine Steady Rubber Mounting	2	.....	.....
7	060493	Engine Steady Stud	2	.....	.....
8	000192	Engine Steady Stud Washer	6	.....	.....
9	060348	Engine Steady Stud Nut	6	.....	.....
10	061410	Front Engine Mounting	1	.....	.....
11	063213	Front Engine Plate Bolt	2	.....	.....
12	30755	Front Engine Plate Washer	4	.....	.....
13	063245	Engine Front Plate Nut	2	.....	.....
14	060423	Front Engine Plate Bolt to Frame	1	.....	.....
15	000008	Front Engine Plate Bolt Washer	2	.....	.....
16	063598	Front Engine Plate Bolt Nut	1	.....	.....
17	061226	Front Engine Mounting Bush	2	.....	.....
18	063960	Front Engine Mounting Spacer	1	.....	.....
19	061278	Front Engine Mounting Buffer	2	.....	.....
20	060684	Front Engine Mounting Tube Cap	2	.....	.....
21	060686	Front Engine Mounting Shim .005"	AR	.....	.....
22	060687	Front Engine Mounting Shim .010"	AR	.....	.....
23	060688	Front Engine Mounting Shim .020"	AR	.....	.....
24	060689	Front Engine Mounting Shim .030"	AR	.....	.....
25	060422	Front Engine Mounting Collar	2	.....	.....
26	063556	Front Engine Mounting Washer ( PTFE.)	2	.....	.....
27	063718	Front Engine Mounting Gaiter	2	.....	.....
28	064060	Rear Engine Mounting	1	.....	.....
29	063212	Rear Engine Plate Bolt	2	.....	.....
30	000010	Rear Engine Plate Washer	4	.....	.....
31	063024	Rear Engine Plate Nut	2	.....	.....
32	063211	Rear Engine Plate Bolt Bottom	1	.....	.....
33	30859	Rear Engine Plate Washer	2	.....	.....
34	063246	Rear Engine Plate Nut	1	.....	.....
35	061227	Rear Engine Mounting Rubber	3	.....	.....
36	063928	Rear Engine Mounting Spacer	2	.....	.....
37	061280	Rear Engine Mounting Buffer	2	.....	.....
38	060685	Rear Engine Mounting Tube Cap	2	.....	.....
39	060775	Rear Engine Mounting Shim .005"	AR	.....	.....
40	060776	Rear Engine Mounting Shim .010"	AR	.....	.....
41	060777	Rear Engine Mounting Shim .020"	AR	.....	.....
42	060778	Rear Engine Mounting Shim .030"	AR	.....	.....
43	060436	Rear Engine Mounting Collar	2	.....	.....
44	063556	Rear Engine Mounting Washer (PTFE.)	2	.....	.....
45	063719	Rear Engine Mounting Gaiter	2	.....	.....
46	063927	Circlip for Isolastic Buffers	8	.....	.....
47	062442	Rear Engine Mounting Stud	1	.....	.....
49	064643	Centre Stand Spring	1	.....	.....
50	062040	Centre Stand Bolt	2	.....	.....
51	000009	Centre Stand Washer	2	.....	.....
52	061702	Centre Stand Nut	2	.....	.....
54	064031	Centre Stand	1	.....	.....
55	064057	Centre Stand Spacer	2	.....	.....
	064874	Kit to fit more robust 850 centre stand to 1971-73 750's (Centre stand included)	1	.....	.....

# Frame, Swinging Arm, Suspension Units

# 14

Plate No.	Part No.	Description	Qty.	Bin No.	Price
1A	065404	Frame	1		
2	063247	Label (Certification) available to Distributor only	1		
3	061287	Rivet	4		
4	063977	Decal	1		
5	062489	Dzus Fastener Assembled	1		
6	061341	Circlip, Fastener	1		
7	061204	Panel Support Bracket	1		
8	060865	Bracket Bolt	1		
9	000012	Bracket Washer	2		
10	033057	Bracket Nut	1		
11	NME6742	Washer (Lipped)	4		
12	064009	Knurled Nut (Dual Seat)	2		
13	060695	Pin for Nut	2		
14	064539	Swinging Arm	1		
15	060446	Cover, Dust	2		
16	060447	Bearing	2		
17	060449	'O' Ring	2		
18	060448	'O' Ring	2		
19	060650	Chain Adjuster	2		
20	060651	Adjuster Nut	2		
21	060453	Pivot Spindle	1		
22	060327	Bolt	1		
23	000012	Washer	1		
24	060869	End Cap	1		
25	060868	End Cap	1		
26	060873	End Cap Rod	1		
27	060871	Washer	1		
28	063411	Oil Nipple	1		
29	062179	Suspension Unit Complete	2		
30	062177	Damper only	2		
31	062178	Spring	2		
32	062290	Collar	4		
33	060465	Suspension Unit Top Bolt	2		
34	000010	Suspension Unit Bolt Washer	6		
35	060029	Suspension Unit Bolt Nut	2		
36	060463	Suspension Unit Bottom Bolt	2		
37	NM.22636	Suspension Unit Bottom Washer	2		
38	NM.23298	Suspension Unit Bottom Washer	2		
39	060029	Suspension Unit Bottom Nut	2		
40	065574	Prop Stand with Buffer	1		
41	065491	Pivot Spacer	1		
42	062592	Prop Stand Spring	1		
43	065492	Stand Nut	1		
44	000009	Washer	1		
46	065436	Pivot Bolt	1		
47	063324	Rubber Buffer	1		
48	064837	Chainguard	1		
48A	065818	Chainguard (Jan. 74—MK2 & MK2A)	1		
49	060459	Bolt, Chainguard	2		
50	000012	Washer	4		
51	033057	Nut	2		
52	064061	Nipple Washer	1		
—	065333	Label—approval mark (E11)	1		

# Support Plates, Riders Footpegs, Rear Brake Pedal and Linkage

15

Plate No.	Part No.	Description	Qty.	Bin No.	Price
1	061228	Right Hand Support Plate	1	.....	.....
2	060944	Left Hand Support Plate	1	.....	.....
3	060858	Bolt	4	.....	.....
4	060471	Spacer, Lower	4	.....	.....
5	000010	Washer	8	.....	.....
6	060029	Nut	4	.....	.....
7	060472	Engine Mounting Stud Washer	2	.....	.....
8	000008	Footrest Support Washer	2	.....	.....
9	063598	Footrest Support Nut	2	.....	.....
10	063118	Left Hand Footpeg Assembly. Less Rubber	1	.....	.....
11	063117	Right Hand Footpeg Assembly. Less Rubber	1	.....	.....
12	062734	Footpeg	2	.....	.....
13	20948	Nut	2	.....	.....
14	NM.19983	Footrest Rubber	2	.....	.....
15	063383	Footrest Mounting Stud	5	.....	.....
16	000011	Washer	5	.....	.....
17	060348	Nut	5	.....	.....
18	061246	Footrest Mounting Bolt	1	.....	.....
19	000011	Washer	2	.....	.....
20	061247	Nut	1	.....	.....
21	061054	Rear Brake Pedal	1	.....	.....
22	000039	Stop Switch Washer	4	.....	.....
23	34815	Stop Lamp Switch	1	.....	.....
24	060651	Stop Bolt Nut	1	.....	.....
25	060677	Stop Switch Screw	2	.....	.....
26	060678	Stop Switch Nut	2	.....	.....
27	060943	Stop Bolt	1	.....	.....
28	021590	Brake Pedal Pivot Washer	1	.....	.....
29	060481	Bolt (Grease Nipple)	1	.....	.....
30	060780	Rear Brake Lever Roller	1	.....	.....
31	060781	Rear Brake Adjusting Collar	1	.....	.....
32	060797	Rear Brake Adjuster Nut	1	.....	.....
33	060796	Rear Brake Cable Yoke	1	.....	.....
34	060806	Rear Brake Cable Trunnion	1	.....	.....
35	060552	Rear Brake Cable Pin	1	.....	.....
36	060553	Spring Clip	1	.....	.....
37	060482	Rear Brake Cable	1	.....	.....

# Oil Tank, Oil Pipes, Junction Block, Rear Chain Oiler and Full Flow Oil Filter

16

Plate No.	Part No.	Description	Qty.	Bin No.	Price
1	063975	Oil Tank	1	.....	.....
2	060636	Oil Tank Mounting	2	.....	.....
3	000012	Washer	4	.....	.....
4	033057	Nut	4	.....	.....
5	060811	Mounting Rubber	1	.....	.....
6	060652	Bolt	1	.....	.....
7	061650	Spacer	1	.....	.....
8	000012	Washer	2	.....	.....
9	065509	Cap	1	.....	.....
10	060668	Plug	1	.....	.....
11	062624	Washer	1	.....	.....
12	063370	Breather Hose Clip	1	.....	.....
13	061159	Filter	1	.....	.....
14	042065	Washer	2	.....	.....
15	064134	Oil Junction Block	1	.....	.....
16	062200	Feed Pipe (17 in.)	1	.....	.....
17	063144	Return Pipe	2	.....	.....
—	065393	Return Pipe	1	Mk2A	.....
—	065420	Feed Pipe	1		.....
18	063248	Clip	2	.....	.....
19	032044	Gasket	1	.....	.....
20	030448	Bolt	1	.....	.....
21	063248	Clip	2	.....	.....
22	062207	Banjo	1	.....	.....
23	061677	Clip	1	.....	.....
24	061669	Chain Oiler Regulator	1	.....	.....
25	060884	Regulator End	1	.....	.....
26	060887	Regulator Felt	1	.....	.....
27	062496	Tube (3.375 in.)	1	.....	.....
28	060886	Clip	2	.....	.....
29	060881	Bracket	1	.....	.....
30	062084	Pipe (12 in.)	1	.....	.....
31	062085	Pipe (3 in.)	1	.....	.....
32	060920	Clip	2	.....	.....
33	060921	Clip	1	.....	.....
34	060459	Oiler Bracket Bolt	1	.....	.....
35	000012	Washer	1	.....	.....
36	033057	Nut	1	.....	.....
37	063367	Protection Spring	2	.....	.....
38	063369	Screw Clip	1	.....	.....
39	063139	Mounting Head S.A.	1	.....	.....
40	065006	Tab Washer	1	.....	.....
41	22403	Screw	2	.....	.....
42	063371	Filter	1	.....	.....
43	063368	Strip. Filter Retainer	1	.....	.....
44	062617	Breather Pipe. Long	1	.....	.....
45	062676	Breather Pipe. Short	1	.....	.....
46	062517	Adaptor	1	.....	.....
47	062283	Pipe	1	.....	.....
48	063961	Battery Rubber	1	.....	.....
Not illustrated	064875	Compression Clip-Chain Oiler	1	.....	.....
—	065571	Breather Pipe	1	MK2A	.....
—	065569	Clip	1		.....
—	065573	Oil Separator	1		.....
—	065499	Tube, Separator to Inlet Pipe	1		.....
—	065315	Tee Piece	1		.....
—	065316	Balance Pipe Hose	2		.....
—	065582	Breather Pipe	1		.....
—	062676	Breather Pipe	1		.....

# Front Forks, Steering Lock, Steering Head Bearings

17

Plate No.	Part No.	Description	Qty.	Bin No.	Price
1	061564	Right Hand Leg Assembly (Drum Brake)	1	.....	.....
2	060352	Right Hand Slider (Drum Brake)	1	.....	.....
3	062456	Right Hand Leg Assembly (Disc Brake)	1	.....	.....
4	063316	Right Hand Slider (Disc Brake)	1	.....	.....
5	061563	Left Hand Leg Assembly (Drum Brake)	1	.....	.....
6	060351	Left Hand Slider (Drum Brake)	1	.....	.....
7	062533	Left Hand Leg Assembly (Disc Brake)	1	.....	.....
8	063318	Left Hand Slider (Disc Brake)	1	.....	.....
9	062465	Pinch Bolt (Drum only)	1	.....	.....
10	061115	Gaiter	2	.....	.....
11	061137	Collar	2	.....	.....
12	000203	Washer	2	.....	.....
13	030584	Damper Rod Seat	2	.....	.....
14	060346	Damper Rod	2	.....	.....
15	060347	Damper Rod Cap Nut	2	.....	.....
16	060348	Damper Rod Locknut	2	.....	.....
17	060354	Slider Drain Plug	2	.....	.....
18	060359	Damper Tube Anchor Bolt	2	.....	.....
19	061347	Damper Tube Cap	2	.....	.....
20	061888	Damper Tube	2	.....	.....
21	NM.14118B	Damper Valve	2	.....	.....
22	NM.14119	Damper Valve Stop Pin	2	.....	.....
23	NM.18813	Fork Spring	2	.....	.....
24	NM.25003	Fork Spring Locating Bush	2	.....	.....
25	NMT1009	Damper Tube Anchor Bolt Washer	2	.....	.....
26	NMT814	Damper Tube Anchor Bolt Washer	2	.....	.....
27	063423	Main Tube	2	.....	.....
28	NM.14298	Fork Tube Bush Circlip	2	.....	.....
29	NMT.1048	Fork Tube Bush	2	.....	.....
30	065483	Oil Seal	2	.....	.....
32	NMT1055	Fork Tube Guide Bush	2	.....	.....
33	060345	Fork Tube Top Bolt	2	.....	.....
34	NMT320	Washer	2	.....	.....
35	063189	Stud	4	.....	.....
36	000012	Washer	4	.....	.....
37	060355	Nut	4	.....	.....
38	0700099	Steering Head Bearing	2	.....	.....
39	0700100	Bearing Spacer	1	.....	.....
40	NM.17429	Washer	1	.....	.....
41	NM.15628	Cover	1	.....	.....
42	061912	Washer	1	.....	.....
43	0700101	Nut	1	.....	.....
44	061911	Socket Screw	2	.....	.....
45A	064078	Lower Yoke	1	.....	.....
46	062332	Plug for Lower Yoke	2	.....	.....
47	064080	Upper Yoke with Stem	1	.....	.....
47A	065538	Upper Yoke with Stem and Neimann Lock	Available	.....	.....
48	062305	Stem Blanking Plug	1	.....	.....
49	NM.19021A	Clip	2	.....	.....
50	060333	Screw	4	.....	.....
51	065448	Lock/Keys	1	.....	.....
52	062028	Right Hand Headlamp Bracket and Top Cover	1	.....	.....
53	062029	Left Hand Headlamp Bracket and Top Cover	1	.....	.....
54	061900	'O' Ring	6	.....	.....
55	22688/2	Bolt	1	.....	.....
56	000011	Washer	1	.....	.....
57	27815	Nut	1	.....	.....
-	065447	Lock Roll Pin (For Neimann Lock only)	1	.....	.....
-	065445	Lock Cover (For Neimann Lock only)	1	.....	.....

# Front Wheel and Brake (Disc Type) 18

Plate No.	Part No.	Description	Qty.	Bin No.	Price
1	061950	Rim and Hub Assembly	1	.....	.....
2	060361	Spindle Nut	1	.....	.....
3	060362	Wheel Spindle	1	.....	.....
4	040100	Bearing, L.H.	1	.....	.....
5	060363	Bearing Lockring	1	.....	.....
6	062867	Hub Shell c/w Bearing, Spacer, etc.	1	.....	.....
7	063919	Spacer	1	.....	.....
8	NM.17721	Bearing, R.H.	1	.....	.....
9	061955	Spacer	1	.....	.....
10	062071	Washer	1	.....	.....
11	NM.E6885	Seal	2	.....	.....
12	NM.19714	Washer	1	.....	.....
13	061951	Rim WM2 - 19	1	.....	.....
14	063924	Spoke, R.H. Inner	10	.....	.....
15	063925	Spoke, R.H. Outer	10	.....	.....
16	063922	Spoke, L.H. Inner	10	.....	.....
17	063923	Spoke, L.H. Outer	10	.....	.....
18	062595	Spoke Nipple, R.H.	20	.....	.....
19	063207	Spoke Nipple, L.H.	20	.....	.....
20	063918	Dust Cover	1	.....	.....
21	062448	Spacer, R.H.	1	.....	.....
22	061885	Disc	1	.....	.....
23	061960	Stud	5	.....	.....
24	060348	Nut	5	.....	.....
25	0700120	Washer	5	.....	.....
26	065173	Caliper Assembly	1	.....	.....
27	061927	*Caliper	1	.....	.....
28	061896	Piston	2	.....	.....
29	061930	Seal	2	.....	.....
30	062187	Seal	1	.....	.....
31	062185	End Plug	1	.....	.....
32	061894	Friction Pads	2	.....	.....
33	061929	Bleed Nipple	1	.....	.....
34	0700291	Screw	2	.....	.....
35	26634	Spring Washer	2	.....	.....
36	064618	Balance Weight, 17 grammes	AR	.....	.....
37	064620	Balance Weight, 25 grammes	AR	.....	.....
Not illus.	064243	Caliper Assembly Repair Kit	AR	.....	.....
—	065143	Disc Scraper	1	.....	.....
—	NM25100	Screw	4	.....	.....

\*Not available separately

Rear Wheel **20**

Plate No.	Part No.	Description	Qty.	Bin No.	Price
1	065744	Rim and Hub Assembly, c/w Bearings, Seals, etc.	1	.....	.....
2	065271	Wheel Axle	1	.....	.....
3	065278	Wheel Axle Nut	1	.....	.....
4	065273	Axle Spacer	1	.....	.....
5	060627	Speedometer Gearbox	1	.....	.....
6	000010	Washer	1	.....	.....
7	060029	Nut	1	.....	.....
8	060314	Brake Cam	1	.....	.....
9	060325	Torque Stop Pin	1	.....	.....
10	060326	Torque Stop Pin Nut	1	.....	.....
11	060327	Bolt	2	.....	.....
12	060329	Cam Bearing Nut	1	.....	.....
13	065826	Cover Plate Assembled	1	.....	.....
Not illus.	065827	Brake Plate complete with Brake Parts	1	.....	.....
14	060334	Cover Plate Outer Spacer	1	.....	.....
15	060701	Bearing Cam and Stay	1	.....	.....
16	060704	Lever Return Spring	1	.....	.....
17	063417	Brake Shoe c/w Lining	2	.....	.....
17A	060013	Brake Shoe Slipper	2	.....	.....
-	065766	Grommet	2	.....	.....
18	NM.14454	Plate	1	.....	.....
19	NM.14506	Washer	1	.....	.....
20	NM.19765	Lever	1	.....	.....
21	NM E5276	Washer	AR	.....	.....
22	NM E5832	Spring	2	.....	.....
23	065290	Left Hand Bearing Spacer	1	.....	.....
24	062074	Cush Drive Buffer (Thick)	3	.....	.....
25	062075	Cush Drive Buffer (Thin)	3	.....	.....
26	040100	Bearing	2	.....	.....
27	060317	Lockring	1	.....	.....
28	065726	Hub Shell	1	.....	.....
29	062069	Inner Bearing Spacer	1	.....	.....
30	062071	Felt Retaining Washer	2	.....	.....
31	NM.18234	Spacer	1	.....	.....
32	063012	Dished Washer	2	.....	.....
33	NM E6885	Seal	3	.....	.....
34	NM.13270	Spacer - Speedometer Gearbox	1	.....	.....
35	NM.19266	Washer, Spindle	2	.....	.....
36	NM.25100	Disc Screw	6	.....	.....
37	017060	Security Bolt	1	.....	.....
38	065730	Rim WM2 - 19	1	.....	.....
39	065729	Spoke	20	.....	.....
40	065727	Spoke, Inner L.H.	10	.....	.....
40A	065728	Spoke, Inner R.H.	10	.....	.....
41	063207	Nipple	40	.....	.....
42	062082	Rear Hub Disc	1	.....	.....
43	065512	Brake Drum	1	.....	.....
44	062067	Dummy Axle	1	.....	.....
45	062072	Felt Retaining Washer	1	.....	.....
46	062889	Felt Seal	1	.....	.....
47	062090	Circlip	1	.....	.....
48	NM.17721	Bearing	1	.....	.....
49	064617	Balance Weight, 17 grammes	AR	.....	.....
50	064619	Balance Weight, 25 grammes	AR	.....	.....

# Controls and Control Cables **21**

Plate No.	Part No.	Description	Qty.	Bin No.	Price
1	019824	Junction Box – Air and Throttle Cables	2	.....	.....
2	060908	Air Cable (Control End) Western-style Handlebars	1	.....	.....
2A	064964	Air Cable (Control End) European Handlebars	1	.....	.....
3	033144	Air Cable (Carburetor End)	2	.....	.....
4	033145	Throttle Cable (Carburetor End)	2	.....	.....
5	061451	Throttle Cable (Twistgrip End) Western-style Handlebars (Std. Twistgrip)	1	.....	.....
5A	064137	Throttle Cable (Twistgrip End) European Handlebars (Std. Twistgrip)	1	.....	.....
5B	064602	Throttle Cable (Twistgrip End) Western-style Handlebars (Quick Twistgrip)	1	.....	.....
5C	064601	Throttle Cable (Twistgrip End) European Handlebars (Quick Twistgrip)	1	.....	.....
5D	064638	Throttle Cable (Twistgrip End) Hi Rider only	1	.....	.....
6	062491	Brake Cable (Front Drum Brake only)	1	.....	.....
6A	062503	Brake Cable (Hi Rider Drum Brake only)	1	.....	.....
7	064963	Clutch Cable	1	.....	.....
7A	062814	Clutch Cable (Hi Rider only)	1	.....	.....
8	062032	Twistgrip, Throttle – Standard (less rubber grip)	1	.....	.....
9	16/091	Twistgrip Rotor only (Standard)	1	.....	.....
10	11/013	Clamping Screw (long)	1	.....	.....
11	11/014	Clamping Screw (short)	1	.....	.....
12	064600	Twistgrip, Throttle – Quick (less rubber grip)	1	.....	.....
13	364/012	Twistgrip Rotor only (Quick)	1	.....	.....
14	11/013	Clamping Screw (Quick Throttle)	2	.....	.....
15	026476	Slotted Abutment	1	.....	.....
16	39949	L.H. Switch Cluster only (Dip Switch, etc.)	1	.....	.....
17	39951	R.H. Switch Cluster only (Direction Indicator, etc.)	1	.....	.....
18	063678	Clutch Pivot Casting (Black with hole for mirror)	1	.....	.....
19	064635	Drum Brake Pivot Casting (Black with hole for mirror)	1	.....	.....
20	062702	Clutch Lever	1	.....	.....
21	062553	Brake Lever (Drum)	1	.....	.....
22	062235	Pivot Bolt	2	.....	.....
23	062240	Pivot Locknut	2	.....	.....
24	062027	Cable Adjuster (2 Drum)	1	.....	.....
25	062237	Cable Adjuster Nut (2 Drum)	1	.....	.....
26	062488	Screw, Switch Clusters (8 Drum)	4	.....	.....
27	062241	Screw, R.H. Switch Cluster (Disc Only)	4	.....	.....
—	22402	Washer, Spring	8	.....	.....
—	065373	Stop Lamp Lead – Hi Rider	1	.....	.....
28	062535	Air Lever, Complete (12/609)	1	.....	.....
29	12/620	Body, Air Lever	1	.....	.....
30	12/606	Cap, Air Lever	1	.....	.....
31	12/557	Lever	1	.....	.....
32	12/033	Spring Washer	1	.....	.....
33	12/607	Pivot Screw	1	.....	.....
34	12/595	Clip	1	.....	.....
35	11/014	Screw	2	.....	.....
36	062828	Cable Tie	4	.....	.....
37	062829	Cable Tie	9	.....	.....
38	062830	Cable Tie	1	.....	.....